


TR37-E & TR39-E

4S & 8M SERIAL

- 1. Handgrip- TRHG
- 2. Back Upholstery 17"- STDS2349BLK
19" - STDS2351BLK
- 3. Push Handle Silver Vein- STDS4S3601
- 4. Back Upholstery Screws (8)- STDS5D5504
- 5. Release Lever- STDS4S1503
Nut Cap- STDS001000
- 6. Seat Rail Guide- STDS1070
- 7a. Brake Tip- STDS4011
b. Brake Left- STDS4S092L
Right- STDS4S092R
- 8. Tipping Sleeve- STDS4020
- 9. Rear Axle Bearing- STDS4S3602
- 10. Hub Cap- STDS4S3603
- 11. Rear Axle- STDS4S3604
- 12. Rear Wheel- STDS4S3605
- 13. Cross Frame 17"- STDS4S36X7 *
19"- STDS4S36X9 *
- 14. Front Axle Bearing- STDS1011
- 15. Front Axle- STDS1002-1
- 16. Front Caster- STDS3J2432
- 17. Front Fork- STDS3J4533
- 18. Fork Stem Bearing- STDS8M4601
- 19. Hanger Pins (4)- STDS5D1069
- 20. Seat Upholstery 17"- STDS2348BLK
19"- PL-STDS2350BLK
- 21. Seat Upholstery Screws (8)- STDS1072-2
- 22. Fork Stem Cap- STDS4S3606
- 23. Armrest Pad- STDSFLVB



- 24. Armrest Screw- STDS002001
- 25. Axle Spacer- STDS3J0951
- 26. Footrest (pr)- TR39SF-SV

*** When stock is gone. the part is no longer available.**

02/26/18